

# XPRESS II STAIR LIFT

INCLINED PLATFORM LIFT FOR STRAIGHT STAIRWAYS



The Garaventa Stair-Lift Xpress II inclined platform lift is designed for straight stairways with no intermediate landings. The Xpress II is safe, reliable, and easy to operate. The Xpress II provides a cost-effective accessibility solution. This lift can be installed with little to no structural modifications. The Xpress II is suitable for public building and residential applications.

# XPRESS II



## STANDARD FEATURES

- 800 x 1250mm ADA compliant platform
- Choice of three standard platform sizes
- Passenger grab rail
- Under platform obstruction sensing plate and bi-directional ramp sensors
- Emergency manual lowering and folding system
- Ready lamp safety indicator
- Power-fold platform and ramps
- Keyed Call Stations
- Keyless platform for easier operation
- Large illuminated platform directional buttons and an emergency stop button
- Powered platform safety arms
- 2 year warranty

## OPTIONAL FEATURES

- Auxiliary power system
- Fold down seat with seat belt
- Side-load platform for installations with confined lower landings
- Keyed platform operation for added security
- Vandal resistant platform lock (electric)
- Attendant remote control
- Narrow platform sizes
- Platform folds automatically if left unattended at landing to keep stairways clear
- Optional RAL colors
- Pedestrian audio visual alert
- Building fire alarm integration
- Outdoor cover (vinyl)
- Extended warranty (5 additional years)  
\*USA/Canada only



The optional fold-down ambulatory seat and seat belt allows a person with limited mobility to comfortably operate the Xpress II.

## SPECIFICATIONS

### Standard Platform Sizes:

800mm x 1250mm (31 1/2" x 49 1/4")  
800mm x 1000mm (31 1/2" x 39 3/8")  
750mm x 900mm (29 1/2" x 35 1/2")

### Optional Platform Sizes:

675mm x 1000mm (26 1/2" x 39 3/8")  
725mm x 1000mm (28 1/2" x 39 3/8")

**Rated Load:** 225 kg (495 lbs)

### Speed:

Up: 4 meters (13 ft.) per minute  
Down: 4.9 meters (16 ft.) per minute

### Operating Controls:

Constant pressure switches, 24 VDC.

**Drive System:** Motor: 0.75 H.P.

**Power Requirements:** 208-240 VAC, 50/60 HZ single phase on a dedicated (North America = 20 amp, International = 15 amp) circuit.

**Power Transmission:** Rack & pinion

### Emergency Use:

A handwheel is provided. Auxiliary power system available.

**Rail System:** Champagne anodized aluminum extrusion with integrally mounted zinc plated gear rack.

**Overspeed Safety:** Mechanical overspeed sensor and lock, with electrical drive cut-out protection.

**Xpress Delivery Time:** Standardized components allow for fast delivery times.

Need Design Assistance?

Call your local Garaventa Lift representative or our Design Hotline at: 1.800.663.6556

## Free Inclined Platform Lifts DVD

Learn about how they work, key features, and the benefits offered. To order, contact your local Garaventa Lift dealer or visit our web site.

## Architects

Many resources are available at [www.garaventlift.com](http://www.garaventlift.com):

- Design Specifications
- Spec-Wizard
- CAD Blocks
- Design and Planning Guides
- Photo Gallery

## Contact us today

Phone: +1 604 594 0422  
Toll Free: 1 800 663 6556  
Web site: [www.garaventlift.com](http://www.garaventlift.com)

Authorized Garaventa Lift Representative

15801-P-PB © Garaventa Lift. As we are continuously improving our products, specifications outlined in this brochure are subject to change without notice.

