

XPRESS II STAIR LIFT

INCLINED PLATFORM LIFT FOR STRAIGHT STAIRWAYS



The Garaventa Stair-Lift Xpress II inclined platform lift is designed for straight stairways with no intermediate landings. The Xpress II is safe, reliable, and easy to operate. The Xpress II provides a cost-effective accessibility solution. This lift can be installed with little to no structural modifications. The Xpress II is suitable for public building and residential applications.

XPRESS II



STANDARD FEATURES

- 800 x 1250mm ADA compliant platform
- Choice of three standard platform sizes
- Passenger grab rail
- Under platform obstruction sensing plate and bi-directional ramp sensors
- Emergency manual lowering and folding system
- Ready lamp safety indicator
- Power-fold platform and ramps
- Keyed Call Stations
- Keyless platform for easier operation
- Large illuminated platform directional buttons and an emergency stop button
- Powered platform safety arms
- 2 year warranty

OPTIONAL FEATURES

- Auxiliary power system
- Fold down seat with seat belt
- Side-load platform for installations with confined lower landings
- Keyed platform operation for added security
- Vandal resistant platform lock (electric)
- Attendant remote control
- Narrow platform sizes
- Platform folds automatically if left unattended at landing to keep stairways clear
- Optional RAL colors
- Pedestrian audio visual alert
- Building fire alarm integration
- Outdoor cover (vinyl)
- Extended warranty (5 additional years)
*USA/Canada only



The optional fold-down ambulatory seat and seat belt allows a person with limited mobility to comfortably operate the Xpress II.

SPECIFICATIONS

Standard Platform Sizes:

800mm x 1250mm (31 1/2" x 49 1/4")
800mm x 1000mm (31 1/2" x 39 3/8")
750mm x 900mm (29 1/2" x 35 1/2")

Optional Platform Sizes:

675mm x 1000mm (26 1/2" x 39 3/8")
725mm x 1000mm (28 1/2" x 39 3/8")

Rated Load: 225 kg (495 lbs)

Speed:

Up: 4 meters (13 ft.) per minute
Down: 4.9 meters (16 ft.) per minute

Operating Controls:

Constant pressure switches, 24 VDC.

Drive System: Motor: 0.75 H.P.

Power Requirements:

208-240 VAC, 50/60 HZ single phase on a dedicated (North America = 20 amp, International = 15 amp) circuit.

Power Transmission: Rack & pinion

Emergency Use:

A handwheel is provided. Auxiliary power system available.

Rail System:

Champagne anodized aluminum extrusion with integrally mounted zinc plated gear rack.

Overspeed Safety:

Mechanical overspeed sensor and lock, with electrical drive cut-out protection.

Xpress Delivery Time:

Standardized components allow for fast delivery times.

Need Design Assistance?

Call your local Garaventa Lift representative or our Design Hotline at: 1.800.663.6556

Free Inclined Platform Lifts DVD

Learn about how they work, key features, and the benefits offered. To order, contact your local Garaventa Lift dealer or visit our web site.

Architects

Many resources are available at www.garaventlift.com:

- Design Specifications
- Spec-Wizard
- CAD Blocks
- Design and Planning Guides
- Photo Gallery

Contact us today

Phone: +1 604 594 0422
Toll Free: 1 800 663 6556
Web site: www.garaventlift.com

Authorized Garaventa Lift Representative

15801-P-PB © Garaventa Lift. As we are continuously improving our products, specifications outlined in this brochure are subject to change without notice.

